


FusionSolar App Quick Settings Operation Procedure



FAQ

Physical Layout Design of PV Modules Using Device Commissioning (optional, for scenarios with optimizers)

Physical layout design of PV modules on the SmartPVMS WebUI (optional, for scenarios with optimizers)

This document applies to the following scenarios:


- Inverter with built-in WLAN for local commissioning
- Inverter with a Smart USB-WLAN Adapter for local commissioning
- In RS485 cascading networking.
- Inverter with a SmartLogger for local commissioning

- The figures are for reference only.
- The initial password for connecting the inverter WLAN is **Changeme**.
- The in to the system. Use the initial password upoinitial password for connecting the Smart USB-WLAN Adapter is **Changeme**.
- The initial password of the **installer** and **Advanced user** is **00000a**. If the system prompts you to set a password, set the password and login first power-on and change it immediately after login.
- To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.

1. Downloading and Installing the FusionSolar App

Method 1: Search for **FusionSolar** in Huawei AppGallery to download and install the app.

Method 2: Access <https://solar.huawei.com> using the mobile phone browser and download the latest installation package.



Method 3: Scan the QR code to download and install the app.



FusionSolar

2. Register an Installer Account (Optional, for Installers Without an Account)

Register the first installer account and create a company account.

Both the email address and username can be used to log in to FusionSolar app.





To create multiple installer accounts for the same company, log in to the FusionSolar app and tap New User.

*Company
*Role
*Plant
*Username
*Password
Photo
Phone
*Email


Cancel OK

3. Log in and Start Setup Wizard


- Local Commissioning Using the Built-in WLAN of the Inverter



Log in to the app as installer user. The initial password of the installer is 00000a. If the system prompts you to set a password, set the password and login first power-on and change it immediately after login.



At the first login, the Quick settings screen is displayed by default.



Set the local grid code of the region.

If Sync phone time is enabled, the time and time zone of the inverter are synchronized with those of the mobile phone.

In a non-cascading scenario, the step of Searching for cascaded inverters is not involved.

The 'Cascaded inverters' setup flow consists of four screens: 1. 'Quick settings' with 'Cascaded inverters 0 pcs' highlighted. 2. 'Networking mode' set to 'RS485' with a 'Searching for cascaded inverters' button. 3. 'Cascaded inverters' showing '1 Inverter' with 'Configuring...' progress at 92%. 4. 'Cascaded inverters' showing '2 Inverter' with 'Searching for cascaded inverters' button. A 'FINISH' button is at the bottom of the final screen.

In a non-Battery scenario, the step of **Energy storage control** is not involved.

Quick settings

Device Mgmt. Communication networking

Basic parameters Energy storage control Completed

SUN2000-XXX-XX

Check whether the detected devices are consistent with the actual connected devices.

Online Offline

Cascaded inverters 0pcs

S DongleA S DongleA

Power meter

Battery HUAWEI-LUNA2000 20.0kWh Optimizer SUN2000-450W-P (0pcs)

Previous Next

You can tap to obtain the detailed working mode information.

Set network parameters and domain name.

WLAN communication

Enabled **Monitor the PV plant through the management system.**

Set the **Domain name** to **intl.fusionsolar.huawei.com** and **Port number** to **27250.**

Select a router that can connect to the Internet and enter the router password.

FE communication

Enabled **Monitor the PV plant through the management system.**

Set the **Domain name** to **intl.fusionsolar.huawei.com** and **Port number** to **27250.**

If **Ethernet** is disabled, the network cable is not connected. Reconnect the network cable.

Quick settings

Device mgmt. Communication networking

Basic parameters Communication networking

The access to the management system must be authorized by the owner.

Monitor the PV plant through the management system.

Dongle

Setting management system parameters

Domain name >

Port 27250

TLS encryption Remote automatic unauthorize

Setting parameters for the inverter to connect to the router.

WLAN LTE-2.4GHz-07DCE8

Password

Previous Next

Quick settings

Device mgmt. Communication networking

Basic parameters Communication networking

The access to the management system must be authorized by the owner.

Monitor the PV plant through the management system.

Dongle

Setting management system parameters

Domain name >

Port 27250

TLS encryption Remote automatic unauthorize

Setting parameters for the inverter to connect to the router.

DHCP

Previous Next

Ethernet

Set network parameters and domain name.

4G communication

Enabled **Monitor the PV plant through the management system.**

Set the **Domain name** to **intl.fusionsolar.huawei.com** and **Port number** to **27250.**

By default, **APN mode** is set to **Automatic**. When this mode cannot be used to access the Internet, set the parameter to **Manual**. In this case, set the parameters related to the SIM card based on the information obtained from the carrier.

Quick settings

Device mgmt. Communication networking

Basic parameters Communication networking

The access to the management system must be authorized by the owner.

Monitor the PV plant through the management system.

Dongle

Setting management system parameters

Domain name >

Port 27250

TLS encryption Remote automatic unauthorize

Dongle parameter settings

APN mode Automatic >

Network mode 4G/3G/2G automatic selection >

Previous Next

Quick settings

Device mgmt. Communication networking

Basic parameters Communication networking

The access to the management system must be authorized by the owner.

Monitor the PV plant through the management system.

Dongle

Signal strength Strong (-32dBm)

IP address xxxxxxxx.xxx.xxx

Subnet mask xxxxxxxx.xxx.xxx

Gateway xxxxxxxx.xxx.xxx

MAC address c0:a8:a9:01



Previous Next

Quick settings are completed. Check the following

- Connect to mgmt sys Success
- Inverter SUN2000-XXXXX 1pcs Grid connected
- Power meter DDSU666-H₁pcs (Single-phase) Online
- Optimizer SUN2000-450W-P 0pcs Searching completed

Previous Finish








Ensure that the devices are consistent with the actual connected devices.



Local Commissioning Using a Smart USB-WLAN Adapter

Note:
Before commissioning a commercial inverter, connect the 4G Smart Dongle to identify parameters. If the indicator status is normal, remove the Smart Dongle, and then connect the USB-WLAN adapter to start commissioning.

Check the indicator status. When the indicator blinks green at an interval of 2s (on for 0.1s and then off for 1.9s), remove the 4G Smart Dongle.



If **Sync phone time** is enabled, the time and time zone of the inverter are synchronized with those of the mobile phone.

In a non-cascading scenario, the step of **searching for cascaded inverters** is not involved.

In a non-Battery scenario, the step of **Energy storage control** is not involved.

Set network parameters and domain name.

4G communication


Enabled **Monitor the PV plant through the management system**.

Set the **Domain name** to **intl.fusionsolar.huawei.com** and **Port** number to **27250**.



By default, **APN mode** is set to **Automatic**. When this mode cannot be used to access the Internet, set the parameter to **Manual**. In this case, set the parameters related to the SIM card based on the information obtained from the carrier.

Ensure that the devices are consistent with the actual connected devices.

Connect to the management system.



After the commissioning is complete, remove the USB-WLAN module, install the 4G module. Check the indicator status. After the indicator is steady green or blinks at short intervals (on for 0.2s and then off for 0.2s) add a PV plant.



Indicators on the Smart Dongle

LED		Remarks	Description
Color	Status		
N/A	Off	Normal	The Dongle is not secured or is not powered on.
Yellow (blinking green and red simultaneously)	Steady on		The Dongle is secured and powered on.
Green	Blinking in a 2-second cycle (on for 0.1s and then off for 1.9s)	Normal	Dialing (duration < 1 min)
		Abnormal	If the duration is longer than 1 min, the 4G parameter settings are incorrect. Reset the parameters.
	Blinking at long intervals (on for 1s and then off for 1s)	Normal	The dial-up connection is set up successfully (duration < 30s).
		Abnormal	If the duration is longer than 30s, the settings of the management system parameters are incorrect. Reset the parameters.
	Steady on	Normal	Successfully connected to the management system.
	Blinking at short intervals (on for 0.2s and then off for 0.2s)		The inverter is communicating with the management system through the Dongle.
Red	Steady on	Abnormal	The Dongle is faulty. Replace Dongle.
	Blinking at short intervals (on for 0.2s and then off for 0.2s)		The Dongle has no SIM card or the SIM card is in poor contact. Check whether the SIM card has been installed or is in good contact. If not, install the SIM card or remove and insert the SIM card.
	Blinking at long intervals (on for 1s and then off for 1s)		The Dongle fails to connect to the management system because it has no signals, weak signal, or no traffic. If the Dongle is reliably connected, check the SIM card signal through the APP. If no signal is received or the signal strength is weak, contact the carrier. Check whether the tariff and traffic of the SIM card are normal. If not, recharge the SIM card or buy traffic.
Blinking red and green alternatively	Blinking at long intervals (red for 1s and green for 1s)	Normal	No communication with the inverter <ul style="list-style-type: none"> Remove and insert the Dongle. Check whether inverters match the Dongle. Connect the Dongle to other inverters. Check whether the Dongle or the USB port of the inverter is faulty.
	Blinking at short intervals (red for 0.2s and green for 0.2s)		The Dongle is being upgraded locally.

3. Log in and Start Setup Wizard

Local Commissioning Using the SmartLogger of the Inverter

The process starts with logging into the FusionSolar app. After successful login, the user enters the 'Plant' section and initiates the 'Setup wizard'. From the main menu, the user selects 'Commissioning'. This leads to a 'Scan' screen where a QR code is scanned. A yellow box instructs the user to 'Log in as Advanced user. The initial password is 00000a.' The user then enters 'Advanced user' and the password '00000a' on the 'Identity authentication' screen. Finally, the user is taken to the 'SmartLogger' dashboard, where the 'Maintenance' option is highlighted.

Add devices.

The process begins in the 'System Maintenance' menu, where 'Device Mgmt.' is selected. In the 'Device Mgmt.' screen, 'Auto Device Search' is used to detect devices. A list of detected devices is shown, including '4.95KTL-JPL0' and '5KTL-L1(COM2-1)'. A yellow box instructs the user to 'Tap Auto Device Search to add inverters. You can also add inverters manually. If not all devices are detected due to duplicate communications addresses, tap Auto Assign Address to assign and adjust the addresses as prompted.' The user then selects 'Add Devices' to add a smart power sensor. A yellow box instructs: 'Tap Add Devices to add a smart power sensor. The DTSU666-H smart power sensor is used as an example. Set Device type to Meter, Port number to the ID of the SmartLogger COM port connected to the smart power sensor, and Address to 11.' The final screen shows the configuration for the '4.95KTL-JPL0(COM1-1)' device, with 'Device type' set to 'Meter', 'Port number' set to 'COM1', and 'Address' set to '11'.

Note: For details about adding devices, see the *SmartLogger User Manual*.

Set the grid code.

SmartLogger Online

Communication status: No SIM card; Management system: Connection failed

Rated power: 9.900 kW; Active power: 0.000 kW

Energy yield of current day: 0.00 kWh; Total: 0.00 kWh

Alarm, Quick settings, Device monitoring, Maintenance, Settings, Power adjustment

4.95KTL-JPL0(COM1-1)

Alarm, Running Info., Settings, Energy Yield, Maintenance, Device logs, About

Device monitoring

- SmartLogger1000A
- Modbus meter
- SUN2000(2)
 - 4.95KTL-JPL0(COM1-1)
 - E-Daily(kWh) 0.00
 - 5KTL-L1(COM2-1)
 - E-Daily(kWh) 0.00

Tap the inverter.

Settings

- Grid code: XXXXXX
- Insulation resistance protection threshold(MΩ): 0.050
- MPPT multi-peak scanning: ON
- MPPT multi-peak scanning interval(min): 10
- Communication interrupt shutdown: OFF
- Communication interrupt duration(min): 30
- Soft start time(s): 20
- Upgrade delay: ON
- HVRT compensation power factor of reactive power in negative sequence: 0.0
- Backup power SOC(%):

Grid code

XXXXXX ✓

XXXXXX

Set the date and time.

SmartLogger Online

Communication status: No SIM card; Management system: Connection failed

Rated power: 9.900 kW; Active power: 0.000 kW

Energy yield of current day: 0.00 kWh; Total: 0.00 kWh

Alarm, Quick settings, Device monitoring, Maintenance, Settings, Power adjustment

Settings

- User param.
 - Date&Time
 - Plant
 - Revenue
- Comm. Param.
 - Device WLAN hotspot
 - Ethernet
 - RS485
 - Power Meter
 - Management System
 - Modbus TCP

Date&Time

Time zone: (UTC+08:00)Beijing

Date: 2020-12-01

Time: 16:19:34



Clock source: Management System

Synchronization server: 10.26.121.151

Latest synchronization time: 2020-12-08 16:07:23

The SmartLogger supports only one clock source pair, set this parameter as required. (If SmartPVMS is connected, you are advised to select **Management System**.)

Set network parameters.





When the SmartLogger connects to the SmartPVMS over the wireless network, set **Monthly traffic package(MB)** and **Network mode**.

Note:

- Set **Monthly traffic package(MB)** and **Network mode** based on the SIM card information.
- By default, **APN mode** is set to **Automatic**. When this mode cannot be used to access the Internet, set the parameter to **Manual**. In this case, set the parameters related to the SIM card based on the information obtained from the carrier.
- When **4G module status** is **Connected** and an IP address has been assigned, SmartLogger dialup is successful.

Set network parameters.






Notes:

- Set **IP address** and **Subnet mask** for the SmartLogger according to the network planning. Ensure that the SmartLogger and the router are on the same network segment and that the SmartLogger has a different IP address from other devices on the LAN.
- Set **Default gateway** and **Primary DNS server** to the IP address of the LAN router.
- If the primary DNS server cannot resolve the domain name, use the secondary DNS server.


When the SmartLogger connects to the SmartPVMS over a wired network, set **Ethernet** parameters.

Or

Connect to the SmartPVMS.




- Set **Server** to **intl.fusionsolar.huawei.com** and **Port number** to **27250**.
- Set **Address mode** to **Logical address**. If the communication address of the device connected to the SmartLogger is unique, you are advised to set **Address mode** to **Comm. address**. In other cases, you must select **Logical address**.
- Enable **TSL encryption** and **Second challenge authentication**.
- If the status of **Management system** is **Connected**, the SmartLogger is properly connected to the SmartPVMS.




After the configuration is complete, return to add a plant.

Add a plant.



Create an owner account.



4. Checking the Device Status

• Checking the Device Status Using Device Commissioning

Mobile phone connected to the Internet

Mobile phone not connected to the Internet

Check the device status using device commissioning.

Connect to the inverter WLAN.


Log in as **Advanced User**.

• Checking the Device Status Remotely.


FAQ 1. Physical Layout Design of PV Modules Using Device Commissioning (Optional, for Scenarios with Optimizers)

Step 1. Check that the SN labels of the Smart PV Optimizers have been attached to the Huawei physical layout template.

Installation positions of PV modules and optimizers




Huawei Physical Layout Template



Template shooting


How do I take a photo of a template?






1. Keep your phone parallel to the template and take a photo in landscape mode.
2. Ensure that the four positioning points in the corners are in the frame.
3. Ensure that the QR code is attached within the frame.

Step 2. Check that the Smart PV Optimizers are successfully searched.

1. Open the **FusionSolar** app, log in to intl.fusionsolar.huawei.com using the installer account, choose **My > Device commissioning**, and connect to the WLAN hotspot of the solar inverter.
2. Select **installer** and enter the login password.



Step 3. Set optimizer physical layout



method 1: Tap **Identify image** for automatic layout.

Tap **Identify image**.

Choose **Photo** or **Choose from album** to upload a physical layout template.

Upload template for identification.

Tap **+** to continue to upload templates.

After all photos are recognized, tap **Next** to generate the layout.

Tap **Submit**. (If the template is unidentified, Bind optimizers by referring to step 4.)

method 2: Tap **Add PV modules** for manual layout.

Tap **Add PV module**.

Select the number of rows and columns for added PV modules.

Tap **+** or **-** to change the number of rows and columns.

Adjust the PV module angle, and tap **Confirm**.

FAQ 1. Physical Layout Design of PV Modules Using Device Commissioning (Optional, for Scenarios with Optimizers)

Step 4. Bind Smart PV Optimizers

The first screenshot shows a 'Physical layout design of PV modules' screen with a grid of modules. A hand icon points to a specific module. The second screenshot shows a dialog box with 'SN: xxxxxxxxxx' and 'Device name: 4617' highlighted by a red box. The third screenshot shows the same layout with a 'Bind' button highlighted by a red box and a hand icon.

Select a PV module to be bound to the optimizer.

Select the corresponding optimizer.

After the layout is complete, tap **Submit**.

Step 5. Check the Smart PV Optimizer status.

The first screenshot shows a 'SUN2000-XXXX-XX' device monitoring screen with a 'Device Monitoring' button highlighted by a red box. The second screenshot shows a 'Device monitoring' screen with a hand icon pointing to a PV string. The third screenshot shows a 'Physical layout design of PV modules' screen with a hand icon pointing to a PV string. The fourth screenshot shows a detailed status screen for an optimizer with the following data:

Running status	Operating
Output power	98W
Input voltage	28.4V
Output voltage	20.7V
Input current	3.53A
Output current	4.74A
Total	98.06kWh
SN	xxxxxxxxxx

Unbind the optimizer.

Step 6. Detect optimizer disconnection.


The first screenshot shows a 'Maintenance' screen with 'Optimizer disconnection detection' highlighted by a red box. The second screenshot shows an 'Optimizer disconnection detection' screen with a hand icon pointing to a play button. The third screenshot shows a progress bar at 5% with the text 'Detecting...'. The fourth screenshot shows a 'Tips' dialog box with 'Are you sure you want to perform optimizer disconnection detection?' and 'Confirm' highlighted by a hand icon.

Rectify the fault based on the detection result.


FAQ 2. Physical Layout Design of PV Modules on the FusionSolar WebUI (Optional, for Scenarios with Optimizers)

Log in to the SmartPVMS WebUI as an intaller user at <https://intl.fusionsolar.huawei.com>.


1. On the **Homepage**, click a PV plant to enter the **Single Power Plant** page.



2. Click **Layout**.





3. Upload a plant drawing and click **Physical Layout**.



Upload the plant drawings for reference.


4. Drag the PV module to the physical layout area, increase the number of widgets, and adjust the angle based on the site requirements.




FAQ 2. Physical Layout Design of PV Modules on the FusionSolar WebUI (Optional, for Scenarios with Optimizers)

5. Select a device in the device list, and drag it to the corresponding icon position to bind the device to the icon.

← Layout Configuration



6. Click  on the toolbar to save the settings.

